


## ARCADE PRO

**ENCENDER ARCADE:** Conectar el cable a la toma de alimentación y a la corriente, poner el interruptor en ON 1 y pulsar el botón de encendido/apagado para encender, el sistema iniciará de forma automática.

**APAGAR ARCADE:** Pulsar el botón de encendido/apagado y se cerrarán todas las aplicaciones de forma automática hasta quedar la arcade totalmente parada. Poner el interruptor de encendido en OFF 0 si se desea y desconectar el cable de alimentación si se prefiere.

### CONTROL AREA

---



### MENÚS

---



ATRÁS/RETROCEDER



BÚSQUEDA POR GÉNERO



Inside the emulator, activate the menu of search filters, categories or favorites



Inside the emulator add or remove game to favorites category

### SPECIAL CONTROLS

---



Exit Game



Pause (In console emulators we can also Pause with Player Start)



Credits (Insert Coin)



Start (Player Start Game)

### SAVE GAME / LOAD GAME


---



Save Game



Load Game



Change Slot

- *It's important to select the slot where we want to save the game, by default SLOT 0*

## ARCADE PRO

- *Some arcade games don't have a save game function*